





## Codici TV - TV codes

@DIKON	1551,1525		
A.R. SYSTEM	0237,0246,0322,0540,1636,5422		
ACCENT	0322,0176,1637,0540,0131		
ACCUPHASE	0540		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1623,1629,1630,1631,1632,1633,1672,1705		
ACEC (PHILIPS)			
ACER	1363,1480,1585		
ACOUSTIC SOLUTION	5422	ADB	5334
ADMIRAL	0024,0080,0222,0428,0429,0440		
ADYSON	0505,0329,0123		
AEA	0513,0540		
AEG	0043,1423,5422,5481,5609,6157		
AG	0557	AGATH	5468
AGASHI	0322,0236,0513		
	0024,0025,0043,0051,0055,0089,0090,0092,0094,0095, 0119,0181,0229,0242,0513,1626		
AGB (SABA)			
AGEF(BRUNS)	0024,0077,0242,0336,0363,1623,1667		
AIKO	0067,0513,1608		
AIM	0237,0329,0352,0354,0508,0513,1302		
AIOSTAY	0136	AIRIS	5965,6165,6166
AIWA	0529,0581,1038		
	0043,0067,0074,0143,0147,0162,0236,0290,0296,0298,0037, 0345,0352,0354,0361,0375,0415,0431,0433,0513,0515,0549, 0558,1243,1311,1314,1396,1423,1623,1636,1652,1659,1684, 5827,5840,5864,5961,5964,6120,6164,6173,6174,6183		
AKAI			
AKARI	1321	AKI	0236,1638
AKIBA	0513,0540	AKIO	1318
AKIRA	0236,0141,0374,1251,1485,1637,5454,5965,6118		
	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300, 0322,0329,0352,0409,0415,0418,0447,0471,0472,0513, 0555,0557,0588,1009,1251,1368,1422,1425,1623		
AKITA (ORION)			
AKITO	0540,0513		
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523, 0557,1423,1608,1678,1681,1694		
AKTRON (TOSHIBA)			
AKURA	0143,0176,0231,0236,0322,0513,0540,5422		
ALBA	0236,0300,0415,0513,1659,5422,5839,5864		
ALBATRON	1378		
ALBIRAL	0025,0125,0236,0237,0322,0513,1174,1639,1659		
ALBRECHT	1586	ALHORI	0067
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523, 0557,1423,1608,1678,1681,1694		
ALKOS (TOSHIBA)			
ALL TEL	0550,1451,0145,1383,5821		
ALLORGAN	0067,0108,0391		
ALTEK	1392,1399,1401,1494,1526,1546,5421,5454		
ALTUS	0557,1603	AMIKO	6180
AMBASSADOR	0196	AMPLIVISION	0067,0237
	0043,0143,0196,0222,0236,0322,0415,0513,1343,1410, 1415,1423,1425,1469,1559,1638,1639,5338,5415,5422, 5437,5481,5851		
AMSTRAD			
ANAM	0513,0540	ANDERSSON	5422
ANEX	1636,1639	ANGLO	0322
ANIS	0322,0336		

ANITECH	0077,0114,0322,0329,0424,0505,0513,0540
ANSONIC	0043,0057,0077,0141,0236,0322,0336,1657,5422
ANTARES	5469,5487 <b>AOC</b> 1540
AQP (GRUNDIG)	0096,0295,0327,0351,0549,1450,1609,1649,1652,1693,1694,
ARCAM	0067
ARCELIK	0141,0230,0557
ARCENCIEL(THOMSON)	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026
ARDEM	0141,0541,0336,0557
ARGENTINA	0568,0569,0570,0572
ARISTONA (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705
ARPHONE (DESMET)	0025,0043,0114,0230,0236,0246,0513,1619
ARTHUR MARTIN (SALORA)	0075,0080,0082,0083,0137,0147,0162,0170,0178,0192,0236,0390,0431,0433,1016,1659
ART-TECH	0424,0513,1638
ASA	0066,0136,0282,0390,0513
AS-BERG	0131,0077,0302,0374,1636,0513
ASORA	0322
ASTHON (EMERSON)	1638,0415,0114,0490,0131,0230,1639,0136,1657,1658,1659,0513,1363,0236,0125,0097,0043,0077,0024,1227,0327,0547,0196,0067,1317,0336
ASTRA	0415,0329,0296,0302,0067,0354,1485
ASTRO SOUND	0237,0230
ASUKA	0067,0322,1659
ATAKI	0424 <b>ATEC</b> 1597
ATLANTIC (FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654
AUDIOLA	5491,5868
AUDIOSONIC	0513,0557,0141,0067,0125,0149,1638,0230,0123,0025,1227,0077,1696,0162,0322,0060,0490,0424,0336,0354,0545,0236,0209,1636,0557,1657
AUDIOTON	0114,0067,0125
AUDIOVOX	0572
AURORA	0024,0067,0354
AUSIND	0131,0136,1126
AUTOVOX	0043,0108,0123,0131,0136,0391,0552,1124,1126,1367,1423,1653,5422,5449,6120
AUVISAT	1456 <b>AVIOUS</b> 1550
AVERMEDIA	1515
AWA	0149,0067,0354,0184,0540,0513,0236
AXXWNT	0236 <b>AXIL</b> 6163
BAIRD	0375,0378,1668,5481
BANG & OLUFSEN	0024,0398
BARCO	1128,0024,0090
BARCOM	0329 <b>BASTIDE</b> 0067
BASIC LINE	0203,1423,0513,0424,0097,0043,0236,0354,0373,0557,0230,0141
BAUER	0069,0114,0236,0275,1302
BAUR	0046,0083,0133,0140,0162,0165,0174,0176,0178,0215,0236,0259,0290,0337,0351,0352,0391,0434,0467,0508

<b>BAUR</b>	0528,1352,1632,1637,1652,1656,1676		
<b>BAUMATIC</b>	0322		
<b>BEAUMARK</b>	0547	<b>BAZIN</b>	0067,0441
<b>BEKNTEKNIK</b>	0337,0207,1657		
<b>BEKO</b>	0141,0207,0227,0230,0236,0336,0540,0541,0557,1400, 1435,1603,6202		
<b>BELSON</b>	1472	<b>BELSTAR</b>	5422
<b>BENNET</b>	0513,0540	<b>BENQ</b>	1593
<b>BENSTEN</b>	1511,0550,0145,1491		
<b>BEON</b>	0513,0540		
<b>BESTAR</b>	0114,0336,0415,0435,0540,0513,1657		
<b>BIAZET</b>	0052,0236	<b>BIFONIC</b>	0067
<b>BIGSTON</b>	0322,0354	<b>BINATONE</b>	0067
<b>BLACK DIAMOND</b>	0043,0540,5422		
<b>BLACK STRIP</b>	1608	<b>BLACKWAY</b>	0351
<b>BLAUPUNKT</b>	0039,0069,0096,0102,0148,0149,0165,0266,0351,0522, 1693,6162,6185		
<b>BLAUSONIC</b>	0067		
<b>BLOOM</b>	0043,1386,1390,1399,1415,1433,5422,5481,5851		
<b>BLUEH</b>	5824	<b>BLUE MEDIA</b>	1590
<b>BLUESKY</b>	0043,0051,0065,0097,0141,0236,0513,0541,0549,0557, 1423,1425,1556,1560,1603,1619,5422,5481,5864		
<b>BLUESTAR</b>	1648,1659,5864	<b>BLUETECH</b>	5825
<b>BLUSENS</b>	6118,6171,6172,6173		
<b>BOCA (AMSTRAD)</b>	0043,0143,0196,0222,0236,0322,0415,0513,1343,1410, 1415,1423,1425,1469,1559,1638,1639		
<b>BONDSTEC</b>	0125		
<b>BOOTS</b>	0067	<b>BOOTS</b>	0067
<b>BOSCH/BAUER</b>	0069	<b>BOSTON</b>	0067
<b>BOTECH</b>	1575	<b>BPL</b>	0513,0540
<b>BRANDT</b>	0051,1435		
<b>BRANDT ELECTRONIQUE (THOMSON)</b>	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136, 0164,0181,0229,0230,0242,0455,0549,0732,1045,1435, 1445,1478,2026		
<b>BRAUN</b>	0067	<b>BRAVO</b>	5456,5493
<b>BRIGMTON</b>	0067,0237		
<b>BRINKMANN</b>	0513,0540		
<b>BRIONVEGA</b>	0295,0247,1367,1124,0222,0024,0428,0223,0440,1181, 1622		
<b>BRITANNIA</b>	0067,0192	<b>BROKLINE</b>	1319
<b>BROKSONIC</b>	0236,1323,		
<b>BROTHER</b>	0043,0322	<b>BROWN</b>	1317
<b>BRUNS</b>	0242,0336,1667,0024,0363,0077,1623		
<b>BSR</b>	0300,0158,0329,1659		
<b>BUSH</b>	0097,0052,0083,0043,0236		
<b>CADMOS (DESMET)</b>	0025,0114,0230,0236,0246,0513,1319		
<b>CALIFORNIA (FORMENTI)</b>	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654		
<b>CAMPER</b>	0141,0336,0513,1696		
<b>CANAIS</b>	0042	<b>CANALERA</b>	1507
<b>CANALSANTE (SIDEK)</b>	0230	<b>CANTON</b>	0252
<b>CANDLE (LG)</b>	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153, 0158,0170,0227,0277,0230,0236,0275,0329,0352,0384, 0513,0529,0542,0547,0555,0557,0587,0925,1439,1459, 1476,1606,1607,1614,1659,3044,4206,4207		

<b>CAPSONIC</b>	0322,1636	<b>CARAD</b>	0513,0540
<b>CARENA</b>	0236,0540		
<b>CARREFOUR</b>	0513,0540,5338		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705		
<b>CARYONSE (PHILIPS)</b>			
<b>CASCADE</b>	0513,0540		
<b>CASIO</b>	0409,0540,1611		
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252, 0431,0433,1626,1654,2356,4340,4341		
<b>CASONIO (OCEANIC)</b>			
<b>CAT</b>	1529,1535,1536,		
<b>CATHAT</b>	0513,0540	<b>CBM</b>	1458
<b>CCE</b>	0513,0540		
<b>CDV</b>	1410,1464,5464,5868,5872,6176		
<b>CELINT</b>	0052	<b>CENTURION</b>	0513,0540
<b>CENTURY</b>	0024,0057,1227		
<b>CEY</b>	1028		
	0057,0102,0131,0227,0298,0473,0374,1636,1638,1650, 1659		
<b>CGE</b>			
<b>CGM</b>	0043,0097,0227,0236,0322,0336,0424,0513,1657,1659		
<b>CIE</b>	0060,0196,0354,0513		
<b>CIHAN</b>	0115,0230	<b>CINEMA</b>	0043
<b>CITIZEN</b>	1324		
<b>CLARITRONIC</b>	1657		
<b>CLARIVOX</b>	0024,0025,0096,0204,0237,0490,0540,1611,1659,1667		
<b>CLATRONIC</b>	0540,5449		
<b>CLAYTON</b>	0043,0230,0513		
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136, 0164,0181,0229,0230,0242,0455,0549,0732,1045,1435, 1445,1478,2026		
<b>COFADEL (THOMSON)</b>			
<b>COLOR MAT</b>	0024	<b>COLUMBIA</b>	0046
	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300, 0322,0329,0352,0409,0415,0418,0447,0471,0472,0513, 0555,0557,0588,1009,1251,1368,1422,1425,1623		
<b>COMBITECH (ORION)</b>			
<b>COMET</b>	0513,0536,1425,1492		
<b>COMPUTRON</b>	0415,0431,0513		
	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153, 0158,0170,0227,0277,0230,0236,0275,0329,0352,0384, 0529,0542,0547,0555,0557,0587,0925,1439,1459,1476, 1606,1607,1614,1659,3044,4206,4207		
<b>CONCERTO (LG)</b>	0043,0114,0131,0227,0236,0259,0322,0374,0424,0513,		
<b>CONDOR</b>	0540		
<b>CONFORAMA(SONOLOR)</b>	0431		
<b>CONIF</b>	0296,0329		
<b>CONRAC</b>	1435		
<b>CONRAD</b>	0043	<b>CONTI M.</b>	0236
<b>CONTEC</b>	0322,0197,0067,0540,0184,0424		
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136, 0164,0181,0229,0230,0242,0455,0549,0732,1045,1435, 1445,1478,2026		
<b>CONTIN.EDIS.(THOMSON)</b>			
<b>CONTINENTAL</b>	0114,0549,1636,1639		
<b>COSMEL</b>	0490,0513,0540,1636		
<b>COSMOS</b>	0513	<b>CRC</b>	0046
	0043,0057,0077,0097,0131,0141,0236,0336,0374,0540, 0541,1420,1639,1657,5338,5422,5864		
<b>CROWN</b>			

CROSLEY	0024,0057,0115,0131		
CRYSTAL	0043,0046,0513,0592,1632		
CS ELECTRONICS	0067,0125		
CTC CLATRONIC	0057,0067,0077,0114,0131,0170,0227,0230,0236,0322, 0374,0415,0424,0513,0557,1423,1603,1636		
CXC(EMERSON)	0024,0043,0067,0077,0097,0114,0125,0131,0136,0196, 0230,0236,0327,0336,0415,0490,0513,0547,1227,1317, 1363,1638,1639,1657,1658,1659		
CYMATIC	0025,0067,1659		
CYV	0513,0540		
DAEWOO	0060,0067,0209,0236,0352,0354,0361,0375,0502,0513, 0545,0554,0557,1390,1412,1449,1450,1453,1601,1644, 5450		
DAICHI	0209	DAIMOND	1637
DAINICHI	0067		
DALMAN	1453		
DANSAI	0067,0329,0513,1608		
DANTAX	0043,1423		
DATRONIC (DAEWOO)	0060,0067,0209,0236,0352,0354,0361,0375,0502,0153, 0545,0554,0557,1390,1412,1449,1450,1453,1601,1644		
DAWA	0513		
DAYMATER(MAGNADYNE)	0024,0025,0060,0077,0115,1009,1639,1659		
DAYTEK	0236,0572,1121		
DAYTRON	0513,0540,1318		
DAYTRONIC(DAEWOO)	0060,0067,0209,0236,0352,0354,0361,0375,0502,0153, 0545,0554,0557,1390,1412,1449,1450,1453,1601,1644		
DCE	0557,1603		
DE GRAAF	0043		
DECCA	0065,0067,0176,0246,0254,0302,0375,0540,0541,1636,		
DEITRON	0513		
DELTON	0557		
DEMACOLOR	0236	DENKO	0322
DENTAL(FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654		
DENVER	0043,1546,1638,5609,6120,6162,6190		
DESMET	0025,0043,0114,0230,0236,0246,0513,1619		
DEWO	1085		
DHS(ASTRA)	0067,0296,0302,0329,0354,0415,1485		
DIADEM	0440	DIAMAT	0513,0540
DIAMOND	0047,0352,0354,1112,1121,1338		
DIBOSS	1516,1517	DICRA	5405,5872,5958,6159
DIGATRON	0513,0540		
DIGIHOME	0557,1435	DIGILINE	0043
DIGITOR	0236,0540,0555		
DIK	0513,0540	DINASTY	0043,0354
DIKOM	5851,5873,5888,5958,5963,5965,6114,6159,6189		
DIKON	1551,5416,5437	DISTAR	50236,1085
DIUNAMAI	1535,1587,5416,5439,5484,5831,5875,5965		
DIXI	0513,0540,1667		
DOMEOS	0236,0434	DMTECH	1489
DOMLAND(DUAL-TEC)	0043,0047,0057,0067,0097,0123,0125,0133,0141,0153, 0158,0162,0170,0196,0209,0222,0230,0236,0298,0312, 0329,0354,0391,0409,0434,0513,0592,1400,1636,1659		
DOMOH	0236,0513,1639		
DORIC	0052	DPM	5446

<b>DTS</b>	0153,0513		
	0043,0047,0057,0067,0097,0123,0125,0133,0141,0153, 0158,0162,0170,0196,0209,0222,0230,0236,0298,0312, 0329,0354,0391,0409,0434,0513,0592,1400,1636,1659,		
<b>DUAL TEC</b>	5422,5449		
	0024,0066,0077,0115,0374,0131,0136,0236,0282,0390, 0513,1619,1636,1639		
<b>DUMONT</b>	0513,1619,1636,1639		
<b>DUNAI</b>	1659		
<b>DURABRND</b>	0043,0552,0557		
<b>DUX</b>	0540	<b>DYNAMTC</b>	0074
<b>D-VISION</b>	0209,0236,0352,0554		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705		
<b>DYNATRON(PHILIPS)</b>	1629,1630,1631,1632,1633,1672,1705		
<b>EASY LIVING</b>	1394,1398,1399,1484,1525,5481,5819,5823,5871,6187		
<b>ECCO</b>	1346	<b>ECO LINE</b>	0236
<b>ECHOSTAR</b>	0067,0236	<b>EDAN LINE</b>	0043,0236
<b>EDISON</b>	0549		
<b>EI</b>	0162,0227,0230,0236,1423,1657		
<b>EL</b>	1394,1398,1399,1484,1525,5481		
	0025,0043,0067,0073,0170,0222,0230,0233,0236,0237, 0255,0295,0428,0429,0440,0528,0541,1425,1449,1450, 1452,1453,1454,1529,1594,1595,1619,1659,5481		
<b>ELBE</b>	1452,1453,1454,1529,1594,1595,1619,1659,5481		
<b>ELCIT(MAGNADYNE)</b>	0024,0025,0060,0077,0115,1009,1639,1659		
<b>ELEKTA</b>	0424,0322,0354,0046,0513		
<b>ELEKTRONSKA IND.</b>	0025,0230	<b>ELEKTRONIKA</b>	0516,1657
<b>ELEMIS</b>	0043,0230,0336		
<b>ELG</b>	0513,0540		
<b>ELIN</b>	0066,0067,0083,0153,0162,0282,0431,0513		
<b>ELITE</b>	0114,0322,0513		
<b>ELLEVISION</b>	0322,0425	<b>ELSAY</b>	0236
<b>ELMAN</b>	0025,0067,0077,0196,1659,1700		
<b>ELTA</b>	0057,0067,0322,0435,0513	<b>E-MOTION</b>	6185
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252, 0431,0433,1626,1654,2356,4340,4341		
<b>EMATEC(OCEANIC)</b>	0431,0433,1626,1654,2356,4340,4341		
	0043,0057,0060,0102,0131,0170,0227,0236,0298,0374, 0435,0513,0522,1227,1619,1636,1650,1659		
<b>EMCO(IMPERIAL)</b>	0043,0057,0060,0102,0131,0170,0227,0236,0298,0374, 0435,0513,0522,1227,1619,1636,1650,1659		
	0024,0043,0067,0077,0097,0114,0125,1227,0131,0136, 0196,0230,0236,0336,0327,0415,0490,0513,0547,1317, 1363,1638,1639,1657,1658,1659		
<b>EMERSON</b>	1363,1638,1639,1657,1658,1659		
<b>ENGEL</b>	0230,1611,6163,6181		
<b>ENIE</b>	0529	<b>EROICA</b>	0329
<b>ENZER</b>	0566,0579,1332		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705		
<b>ERRES(PHILIPS)</b>	1629,1630,1631,1632,1633,1672,1705		
<b>ESC</b>	0067,0336,0236,0513,0540		
<b>ESTEL</b>	0230	<b>ETCO</b>	5338
<b>ETRON</b>	0384,0415,0513,1063,1082,1648		
	0025,0043,0067,0073,0170,0222,0230,0233,0236,0237, 0255,0295,0428,0429,0440,0528,0541,1425,1449,1450, 1452,1453,1454,1529,1594,1595,1619,1659		
<b>EULANDER(ELBE)</b>	1452,1453,1454,1529,1594,1595,1619,1659		
<b>EUMIG</b>	0114	<b>EUROCOM</b>	0230
<b>EUROLINE</b>	1631,1636,5338		



EUROMAN	0067,0322,0336,0513
EUROPA	0513,0540
EUROPHON	0025,0067,0077,0114,0127,0230,0238,0238,1227,1659
EUROSTATUS	0043 EUROVISION 1423
EXCEL	0513,0540 EVELUX 0592 EVERLINE 6186
EXPERT	0153,0204,1654
EXQUISIT	0513,0540 FAGOR 0435,0513
FAMILY LIFE	0513,0540
FELIX	0236,0322,0415
FENNER	0354,0424,0513,0516,1623
FERGUSON(THORN)	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455, 0513,1616,1663,1700
FIDELIS	0043,0067,0296
FIDELITY	0067,0176,0329,0391,0415,0513,1713
FILSAI	0067 FINLANDIA 0083
FINLUX	0043,0066,0077,0115,0127,0131,0136,0137,0147,0170, 0230,0236,0246,0282,0295,0374,0375,0390,0431,0433, 0513,0557,0558,1126,1425,1603,1623,5422,5481
FIRST LINE	0043,0057,0067,0097,0114,0123,0176,0177,0203,0230, 0237,0298,0302,0352,0354,0375,0391,0440,0513,0541, 0557,1009,1420,1425,1435,1453,1636,1654,1659,5338, 5422
FISHER	0363,0133,0066,0123,0314,0115,0197,0149,0184,0290, 0024,0391,0373,1131,1657,1658
FLINT	0073,0513,5873,6160 FLORIDA 0067
FORCE	1329,1330 FNR 0077
FORGESTONE(THORN)	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455, 0513,1616,1663,1700,
FORMENTI	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654
FORTRESS	0024 FRABA 0236
FRIAC	0077,0513,0540
FRONTECH	0057,0083,0329,0125,1659,1696
FST(DECCA)	0065,0067,0176,0246,0254,0302,0375,0540,0541,1636
FUJI	0424
FUJITECH	0513
FUJITSU	0043,0077,0067,0108,0153,0158,0222,0236,0282,0329, 0513,1345,1408
FUMEO	0158
FUNAI	0149,0230,0322,0552,0557,1588,1663,5422,5449,5835
FUSION	0557,1435 FURICHI 0595
FUTURE	0513,0540 FUTRONIC 0322
FUTURETECH(EMERSON)	0024,0043,0067,0077,0097,0114,0125,0131,0136,0196, 0230,0236,0327,0336,0415,0490,0513,0547,1227,1317, 1363,1638,1639,1657,1658,1659
GALA	0296,0329 GALACTEX 0067,0322
GALANT	0415,0424
GALAXI(FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654
GALAXY	5458,5460
GALAXY-GALAXIS	0057,0067,0227,0236,0374,0409,1636
GBC	0060,0115,0125,0197,0354,0375,0415,0424,0513,1489, 1659,5473
GE	0051,0242,0547,1495

	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,		
<b>GEANTCASINO(OCEANIC)</b>	0431,0433,1626,1654,2356,4340,4341		
<b>GEBER</b>	0162		
<b>GEC</b>	0067,0083,0189,0236,0246,0375,0513,1076,1372,1626,		
<b>GELOSO</b>	0025,0060,0080,0115,0354,1659		
<b>GENERAL</b>	0046,0067,0197,0209,0354,0513,5823		
<b>GENERAL CORPORATION</b>	0043,0067,0108,0153		
<b>GENESIS</b>	0513,0540		
<b>GENERAL TECHNIC</b>	0354		
<b>GENEXXA</b>	0540,0162,0390		
<b>GERICOM</b>	1383		
<b>GIANT</b>	0046,0067,0527		
<b>GITEM</b>	0046,0242,1609,1636		
<b>GM - GMC</b>	0322,0513,1663		
<b>GOLD</b>	1526,5420,5845,5851,5866,5870		
<b>GOLD TOP</b>	0424	<b>GOLDFUNK</b>	0094
<b>GOLDHAND</b>	0067		
<b>GOLDLINE</b>	0073		
	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153,		
	0158,0170,0227,0277,0230,0236,0275,0329,0352,0384,		
	0513,0529,0542,0547,0555,0557,0587,0925,1439,1459,		
<b>GOLDSTAR(LG)</b>	1476,1606,1607,1614,1659,3044,4206,4207		
<b>GOLDTECH</b>	0043,0097,0236		
<b>GOLDIVISION(SONOKO)</b>	0123,0236,0322,0424,0505,0513,0557,1636		
	0043,0051,0067,0097,0141,0209,0242,0322,0327,0352,		
	0354,0415,0513,0541,0545,0554,1423,1603,1608,1636,		
<b>GOODMANS</b>	1659,5422,5481		
<b>GORENJE</b>	0051,0236,0516,0592,1296,1423,1657,1658		
<b>GPM</b>	0322,0329	<b>GRADIENTE</b>	0502
	0043,0052,0062,0066,0083,0096,0108,0136,0149,0153,		
	0162,0192,0236,0252,0290,0322,0327,0374,0390,0391,		
<b>GRAETZ(ITT)</b>	0433,0513,1423,1626,1654,1713		
	0043,0052,0062,0066,0083,0096,0108,0136,0149,0153,		
	0162,0192,0236,0252,0290,0322,0327,0374,0390,0391,		
<b>GRANADA</b>	0433,0513,1423,1626,1654,1713		
	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230,		
	0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,		
<b>GRANDEN(FORMENTI)</b>	1639,1654		
	0043,0073,0114,0141,0170,0209,0230,0236,0352,0422,		
	0424,0541,0557,1383,1412,1425,1453,1548,1549,1564,		
<b>GRANDIN</b>	1569,1603,1654,5422,5481,5864		
<b>GREAT WALL</b>	0322,0490	<b>GRANPRIX</b>	5481
<b>GRENADIER</b>	0230,0513,0547,1174		
<b>GRONIC</b>	0067,0230,0238,1174,1659		
	0096,0295,0327,0351,0549,1491,1450,1609,1649,1652,		
<b>GRUNDIG</b>	1693,1694,5334,5864,6202		
<b>GTRONIC</b>	0236,1084	<b>GUTTA</b>	1084
<b>GTT</b>	0043,0236,0374,0424,1638		
<b>H &amp; B</b>	0043	<b>HADOR</b>	1338
<b>HAIER</b>	0209,5474,5848,6162	<b>HALIFAX</b>	0322
<b>HAMMERSTEIN</b>	0067,0322,0384,0422,1082	<b>HAMPTON</b>	0067,0115
<b>HANNOVER</b>	1420	<b>HANNSPREE</b>	5819,5822,5867,5960
	0025,0067,0114,0162,0195,0209,0230,0236,0296,0336,		
	0391,0424,0435,0513,0554,0557,1601,1638,1639,1644,		
<b>HANSEATIC</b>	1693		
<b>HANTAREX</b>	0025,0077,0238,1383,1436,1636		

HARWOOD	0513,0540	HARROW	0043
HAUPPAGE	0513,0540		
HB	0557,1400,1459,1489,1603,5422		
HCM	0123,0322,0424,0513,0543,0540,1659		
HEDZON	0513,0540	HEIRU	0322
HELECTRONIC (FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654		
HEMMERMANN	0077,0127,0391,1009		
HEXA	0204,0230	HENA	0513
HIFIVOX(THOMSON)	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136, 0164,0181,0229,0230,0242,0455,0549,0732,1045,1435, 1445,1478,2026		
HIGASHI	0067	HIGHLINE	0513,0540
HIGHIWA(KAISUI)	0424,0067,0236,0415,0073,1420		
HIKONA(KAISUI)	0067,0073,0236,0415,0424,1420		
HILINE	0236,0322,0415		
HINARI	0065,0080,0322,0327,0329,0363,0513,5864		
HISAWA	0073,0236,0557		
HISENSE	0083,0145,0352,0376,5481,6157,6175		
HISHITO(TOSHIBA)	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523, 0557,1423,1608,1678,1681,1694		
HISONIX	0415		
HIT	0024		
HITACHI	0037,0043,0052,0067,0082,0083,0094,0095,0119,0137, 0142,0147,0160,0178,0189,0197,0209,0285,0296,0326, 0329,0358,0431,0433,0473,0499,0525,0547,0554,0569, 1016,1076,1259,1423,1501,1626,1644,5422,6114,6201		
HITSU	0073,0513	HOME ELECTRONICS	1437
HOHER	0043,1516,1400,0170,1603,1383,1423,5422		
HORIZONTAL(PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705		
HORNYPHON	0513,0540		
HOSHAI	0043,0097,0424		
HOSPITALIERE	0043	HOWELL	0043
HYD	1467,1550	HUMAX	5818
HYPER	0067,0125,0230,0236,0322,0329,0336,0415,0424,0435, 0497,0513,1638,1639,1659		
HYPSON	0025,0043,0097,0141,0170,0209,0236,0336,0557,1425, 1434,5422,5864		
HYUNDAI	1449,1468,1475,1512,1554,1568,5429,5422,5437,5449, 5468,5481,5824,5833,5865,5869		
I CAN	5334	I. V.	0513
IBERIA	0428,0513	IBERVISAO	0391
ICE	0046,0057,0067,0236,0322,0415,0540		
ICS	0067,0322	IEG	0067
IMPER	0322	IJOY	6170
IMPERIAL	0043,0057,0060,0102,0131,0170,0227,0236,0298,0374, 0435,0513,1227,1619,1636,1650,1659,5468,5492,5494	IKEA	6208
INCOBE	0123,0290	IMC	0508
INDESIT	0107	INDIANA	0513
INGELEN	0162	INGERSOLL	0513
INNO HIT	0025,0043,0067,0075,0077,0115,0209,0227,0296,0332, 0375,0415,0424,0513,1423,1633,1638,1639,5965		

INNO HIT	2058,4367,5407,5422		
INNOVATION	0513,0540		
INTERBUY	0125,0176,0322,0415,0505,0540		
INTERDISCOUNT	0092,0119,0242,1352,1636,5338		
INTEREACTIVE	0176,0513,0540		
INTERECORD	0133		
	0042,0046,0047,0062,0069,0079,0092,0096,0162,0302,		
INTERFUNK	0352,0374,0513,1617,1626,1632,1636,1654		
INTERNAL	0513,0540		
	0046,0067,0077,0209,0322,0351,0435,0505,0540,0542,		
INTERVISION	1657,1659		
INTRON	0322	INWAH	0209
IPURE	5609		
	0043,0075,0097,0125,0136,0230,0236,0322,0296,0329,		
IRRADIO	0415,0513,0528,0557,1084,1126,1269,1296,1439,1400,		
	1459,1516,1517,1525,1636,1638		
ISKRA	0025,0067,1659		
ISUKAI	0424,0513	ITAL TV	6203
ITC	0067,0230,0236		
ITS	0067,0236,0322,0415,0540		
	0043,0052,0062,0066,0083,0096,0108,0136,0149,0153,		
ITT	0162,0192,0236,0252,0290,0322,0327,0374,0390,0391,		
	0433,0513,1423,1626,1654,1713		
ITT/NOKIA	5415,5422,5481,5823,5864,5877,6114,6178,6183,6190		
ITV	0060,0322,0354,0540	IZUMI	6182
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523,		
JEC (TOSHIBA)	0557,1423,1608,1678,1681,1694		
JET POINT	0384,1636	JMB	0513,0540
JOCEL	0236,0435		
JOHNSON	0067	JPS	0505
JQ	5415,5468		
JRC	0435		
JUBILEE	0540		
JVC	0167,0316,0404,0415,0502,1470,1479,1622,1696,1697		
KABEL	0300	KAIDO	0083
KAISER	0424,0513		
KAISUI	0067,0073,0236,0415,0424,1420		
KAMAR	0515	KAMOSONIC	0123
KAMBROOK	0067,0119,0230,0322		
	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,		
KAMP(FORMENTI)	0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,		
	1639,1654		
	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,		
KANGSLEY(FORMENTI)	0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,		
	1639,1654		
	0067,0075,0082,0170,0209,0227,0296,0312,0322,0352,		
KAOSHO(SAMSUNG)	0375,0384,0422,0453,0513,0515,0528,0542,0547,0565,		
	1328,1356,1382,1404,1405,1644,1657,1658,2066,4267,		
	0043,0052,0062,0066,0083,0096,0108,0111,0136,0149		
KAPSCH (ITT)	0153,0162,0192,0236,0252,0290,0322,0327,0374,0390,		
	0391,0433,0513,1423,1626,1654,1713		
KATHREIN	0513		
KAWA	0415		
	0067,0111,0209,0236,0237,0238,0424,0435,0513,0516,		
KARCHER	1636		
KAWASHO(FORMENTI)	0025,0043,0067,0083,0111,0114,0115,0136,0170,0227		

	0230,0236,0322,0354,0435,0513,0541,0542,1619,1636, 1637,1639,1654
<b>KAWASHO(FORMENTI)</b>	
<b>KB ARISTOCRAT</b>	0162,0391 <b>KAYA</b> 0322
<b>KELCINATOR</b>	0062 <b>KEN</b> 1317
<b>KENDO</b>	0043,0051,0073,0077,0080,0295,0300,0440,0542,1227, 1636,1659,5422,5449
<b>KENNEDY</b>	0108,0115,0153,0158,0222,0429
<b>KENNEX</b>	0043,0097,0209,0236,0550,0552,0557,0921,1423,4367, 5422
<b>KENSTAR</b>	1469,5415,5484,5486,5492,5823,5833 <b>KENYA</b> 1327
<b>KERION</b>	0513,1639 <b>KEYSMART</b> 1400
<b>KEYMAT</b>	0117,0417,0480,0517,0519,0550,0553,0578,1386,1388, 1391,1426,1496,1541,2395,4551,5821,5823
<b>KIC</b>	0067,0237,0515
<b>KIMAY</b>	0322 <b>KINGHOME</b> 0043
<b>KIOTA</b>	0322,0415,1082
<b>KITON</b>	0043,0513,0540,5422
<b>KITT</b>	0067,0322,0513
<b>KITTEN</b>	0513
<b>KIYOGIN</b>	0067,0025,0237,1174,1659
<b>KLARMAX</b>	0073,0170,0209,0233,0236,0237,0295,0354,0429,0513, 0541,1611
<b>KOBALTRONIC(NEWMAR)</b>	0067,0123,1174,1659
<b>KOLSTER</b>	0067,0077,0237,0322,0513,1174,1227,1614,1659
<b>KONG WAM (KAISUI)</b>	0067,0073,0236,0415,0424,1420
<b>KONKA</b>	0145,0177,0352,0415,1116,1261,1302,1420
<b>KONTAKT</b>	0549 <b>KORPEL</b> 0513,0540
<b>KOSMOS</b>	0513,0540
<b>KOTRON</b>	0230,0322 <b>KRAKING</b> 0230
<b>KRIESLER (PHILIPS)</b>	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705
<b>KRONNE</b>	0067,0230 <b>KTV</b> 1500
<b>KUBA ELECTRONIC</b>	0067,0083,0133,0230,0391
<b>KUCCAI</b>	0097
<b>KURO (SANYO)</b>	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314, 0363,0373,0375,1360,1423,1657,1658,1661,1668
<b>KYOTO</b>	0230,0246
<b>L&amp;S ELEKTRONIK</b>	0557
<b>LAVA</b>	1516,1517
<b>LAVIS</b>	0025,0162,1611
<b>LAZER</b>	0236 <b>LCE</b> 0415
<b>LECSO</b>	0513,0540
<b>LEGEND</b>	0067,0322,0490,0513
<b>LENCO</b>	0043,0077,0162,0236,0322,0329,0354,0391,0435,0513, 5422,6204
<b>LENOIR</b>	0043,0067,0097,0141,0322,0236,0354,0409,0424,0513, 1009,1343,1394,1396,1398,1399,1400,1401,1638,1639, 5871
<b>LEVIS AUSTRIA</b>	0513,0540
<b>LEXUS</b>	0074,0236,0322
<b>LEYCO</b>	0236,0322,1646
<b>LG</b>	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153, 0158,0170,0227,0277,0230,0236,0275,0329,0352,0384, 0513,0529,0542,0547,0555,0557,0587,0925,1439

	1459,1476,1606,1607,1614,1659,3044,4206,4207,5417,		
<b>LG</b>	<b>5443,5496,6113</b>		
<b>LIFE</b>	1435		
	0043,0097,0209,0236,0322,0354,0513,0536,0555,0557,		
<b>LIFETEC</b>	1638,5422,5449		
<b>LIGTHSTAR (KAISUI)</b>	0067,0073,0236,0415,0424,1420		
<b>LINTON</b>	0133		
<b>LLOYD'S</b>	0067,0096,0136,0322,0415,0422,0515,1082,1626		
<b>LME (PATH CINEMA)</b>	0025,0067,0114,0204,0230,0237,0435,1659		
<b>LOCATEL</b>	1580,1581,1582,1583,1584		
	0024,0047,0050,0176,0246,0277,0400,0402,0508,0925,		
<b>LOEWE</b>	1570,1637,2345,4257,4345		
<b>LOGIK</b>	0043,0097,0374,0384,0422,0513		
	0025,0043,0067,0073,0170,0222,0230,0233,0236,0237,		
<b>LOVE (ELBE)</b>	0295,0428,0429,0440,0528,0541,0255,1425,1449,1450,		
<b>LS ELEKTRONIK</b>	1452,1453,1454,1529,1594,1595,1619,1659		
	0557		
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,		
<b>LTV (OCEANIC)</b>	0431,0433,1626,1654,2356,4340,4341		
	0043,0067,0080,0108,0153,0158,0222,0259,0295,0352,		
<b>LUMA</b>	0354,0513		
<b>LUMATRON</b>	0043,5422		
<b>LUXMAY</b>	0490,0513,0540		
	0052,0075,0082,0083,0123,0137,0147,0162,0170,0178,		
<b>LUXOR</b>	0192,0252,0390,0431,0433,1016,1704,1713,5449		
<b>LUXTRONIC</b>	5422	<b>LXI</b>	0547
	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153,		
<b>LYOTRON (LG)</b>	0158,0170,0227,0277,0230,0236,0275,0329,0352,0384,		
	0513,0529,0542,0547,0555,0557,0587,0925,1439,1459,		
	1476,1606,1607,1614,1659,3044,4206,4207		
<b>M.D.C</b>	1638		
<b>MACROM</b>	0480		
<b>MADISON</b>	0236,0540,1636		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,		
<b>MAGAVOX (PHILIPS)</b>	0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,		
	1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,		
	1623,1629,1630,1631,1632,1633,1672,1705		
<b>MAGNADYNE</b>	0024,0025,0060,0077,0115,1009,1639,1659		
<b>MAGNAFON</b>	0025,0067,0077,0131,0238,1126,1636,1639,1659		
<b>MAGNAVOX</b>	0046,1623		
<b>MAGNEX</b>	0322,1636		
<b>MAGNUM</b>	0141,0255,0374,1415,1638		
<b>MAJESTIC</b>	1343,1595,5437,5454,5477,5478,5479,5868,5875		
<b>MAKROSONIC</b>	1324		
<b>MANDI</b>	0352	<b>MANDOR</b>	0322
<b>MANESTH</b>	0052,0067,0114,0236,0322,0540,1608,1623,1654		
<b>MANHATTAN</b>	0043,0097,0513,5422		
<b>MARANTZ</b>	0513,0528	<b>MARECH</b>	0114,0513
<b>MARK</b>	0336,0354,0513		
<b>MASCOM</b>	0236	<b>MASCOT</b>	0057
<b>MASUDA</b>	0236,0300,0322,0513		
<b>MATCH ITALIA</b>	0322,0513,1636		
<b>MATSIKA</b>	0067,0322	<b>MATSUVIANA</b>	0528
	0060,0065,0067,0196,0236,0269,0322,0300,0336,0351,		
<b>MATSUI</b>	0397,0415,0536,0549,1016,5449,5839,5864		
<b>MAXDORF</b>	0322,1084	<b>MAXAM</b>	0322

MAXELL	0025,0329,0424,5564,5842,5843		
MAXIMAL	1648	MB LINE	0322
MAXWELL	0025,0077,0236		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623		
MC MICHAEL (PHILIPS)	1629,1630,1631,1632,1633,1672,1705		
MCE	0322,0425,0513		
MECOA	0236	MEDIASONIC	0236
MEDIATOR	0513,0540		
	0043,0097,0209,0236,0352,0552,1396,1412,1435,1455, 1638,5422,5449,5864		
MEDION			
MEGATRON	0547	MEGHA	0513
	0024,0025,0096,0111,0204,0237,0490,0540,1611,1659, 1667		
MELBOX (CLARIVOX)			
	0060,0066,0133,0136,0137,0147,0181,0209,0236,0282, 0295,0351,0354,0390,0508,0513,0588,1009,1614,1631, 1638,1644,4340,4341,5338		
MELECTRONIC			
MELVOX	0025,0162	MEMOREX	0322
MEMPHIS	0067,0322,0490		
MERCURY	0046,0067,0236,0237,0322,0384,0515		
MERRIT	0162	METEOR	0238
	0024,0043,0079,0097,0338,0349,0351,0402,0460,0462, 0552,1487,1499,1609,5422		
METZ			
MGA	0322,0354,0513,0547,1637		
MGAON	0322	MICRON	0067
MICROMAXX	0043,0236,0295,0540		
MICROSONIC	1131	MIGROS ELECTR	0295
MICROTEK	0236,0242,1084,1127		
MIIA	6176	MINATO	0513,0540
	0096,0295,0327,0351,0549,1491,1450,1609,1649,1652, 1693,1694		
MINERVA (GRUNDIG)			
MINERVA FRANCE	0549	MINOKA	0513,0540
	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455, 0513,1616,1663,1700		
MISTRAL (THORN)			
MITRONIC	0329		
	0024,0043,0047,0065,0149,0197,0230,0353,0354,0425, 0527,0547,1379,1637,1644,1661		
MITSUBISHI			
MITSUTI GENERAL	0233,0298		
MIVAR	0105,0408,0025,0058,0068,0067,0075,5451,5605		
MKC	0578	MKM	0238
MOBILE TV	0043		
	0077,0083,0108,0114,0133,0153,0176,0238,0513,0540, 1126		
MOTION (UHER)			
MPMAN	5471,6119		
MTC	0083,0176,0296,0336,1296,1657,1659		
MULTIMAT	0238	MULTISTANDARD	0077
	0025,0043,0067,0077,0125,0141,0149,0162,0178,0209, 0230,0236,0322,0336,0354,0490,0513,0545,0557,1227, 1614,1657,1696		
MULTITECH			
MURPHY	0083,1626,1696		
MUSIKLAND	0513,0540	MUSTAG	1121
MYRYAD	0513,0540	MYTV	6119
		MVISION	5488
NAD	0162,0391,0547		
NAGOYA	0230,0441	NAIKO	0513,0540
NAKAMURA	0513,0540		

	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242, 0295,0352,0390,0428,0429,0435,0440,0522,0541,1181, 1623,1642,1653
<b>NAONIS (SELECO)</b>	
<b>NARITA</b>	0067,0322,0354,0547
<b>NASSA NAGEL(ENGEL)</b>	0230,1611
<b>NATIONAL</b>	0310,0518
<b>NEC</b>	0149,0065,0427,1418,0472,0447,0430,1336,0237,0354, 0513,5822,5822-5867
<b>NECKERMANN</b>	0024,0046,0047,0057,0060,0069,0080,0083,0114,0133, 0140,0148,0167,0170,0174,0176,0178,0195,0209,0215, 0227,0230,0236,0295,0300,0312,0337,0351,0352,0374, 0409,0467,0508,0513,0540,0541,0555,0588,1352,1609 1629,1361,1632,1636,1638,1639,1656,5338
<b>NEI</b>	0043,0230,0236,0435,0490,0541,0513,1636,1659
<b>NEO</b>	6114,6203
<b>NEOVIA</b>	1301,1383,1459,1450,1516,1517,1542,1543,1568,5468
<b>NESCO</b>	0125,0312,0327,0375,0440
<b>NETSAT</b>	0513,0540
<b>NEUFUNK</b>	0043
<b>NEVIR</b>	6120,6161,6190,6203
<b>NEW GOLDVISION (SONOKO)</b>	0123,0236,0322,0424,0505,0513,0557,1636
<b>NEWMAR</b>	0067,0123,1174,1659
<b>NEWORLD (KAISUI)</b>	0067,0073,0236,0415,0424,1420
<b>NEWTECH</b>	0067,0236,0242
<b>NEXIUS</b>	0588,1393,1422,1425
<b>NEXTIER</b>	1518
<b>NFREN</b>	1555, 0025,0043,0067,0083,0114,0115,0136,0170,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654
<b>NICAMAGIC(FORMENTI)</b>	
<b>NIKKAI</b>	0067,0082,0141,0322,0329,0513
<b>NIKKEI</b>	0043,0097,0170,0322,1399,1425,1467,1550,1537,1636, 5481,5609,5825,5839,5851,5872,5957,6190
<b>NIKKEY</b>	5483
<b>NISSAN</b>	0384
<b>NIKKO</b>	0513,0547
<b>NOBLEX</b>	0149,0184,0197,0354,0415,0422,1327,1661
<b>NOBLIKO</b>	0067,0131,0136,1126,1227
<b>NOGAMATIC(THOMSON)</b>	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136, 0164,0181,0229,0230,0242,0455,0549,0732,1045,1435, 1445,1478,2026
<b>NOKIA</b>	0043,0066,0147,0162,0236,0252,0322,0390,0431,0433, 0558,1423,1704,5500
<b>NORDING</b>	0077,0131
<b>NORLAND</b>	0230
<b>NORDMENDE</b>	0049,0052,0062,0090,0092,0094,0095,0115,0119,0170,0229, 0242,0352,0424,0455,0557,1045,1400,1422,1423,1425,1435, 5415,5486,5492,5819,5823,5832,5833,5864,5871,6188,6203
<b>NORDTON (SELECO)</b>	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242, 0295,0352,0390,0428,0429,0435,0440,0522,0541,1181, 1623,1642,1653
<b>NORDWAY</b>	0298,1657
<b>NORFOLK</b>	0441
<b>NORMEREL</b>	0540,1630
<b>NORM N</b>	1636
<b>NORTEK</b>	0097,0141,1636
<b>NORWAY</b>	0298,1657
<b>NORTON</b>	0424
<b>NOVAK</b>	0513,0540
<b>NOVA</b>	0329
<b>NOVATRONIC</b>	0209,0236,0322,0329,0354,0513,1636
<b>NUCLEAR(PRANDONI)</b>	0077,0080,0083,0097,0115,0302,0352,0592



NUCLEAR(PRANDONI)	1126,1227		
OGENERAL	0149	OCTAL	0067
OCEANIC	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252, 0431,0433,1626,1654,2356,4340,4341,5468		
OCTAN (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705		
ODEON (AGASHI)	0236,0322,0513		
OEC ELECTRONIC	0329,1494	OK	6212
OKANO	0227,0302,0513		
OLIDATA	1378	OLIVETTI	1379
OLMAL (ALBIRAL)	0025,0236,0237,0513,0322,0125,1659,1174,1639		
OLYMPIA	1423	OLYMPIC	0424
OMEGA	0322,0415	ONCEAS	0060,0067
ONDIOLA	0236	ONIDA	0302
ONWA	0077,0322,0361,0415		
OPERA	0513,0540	OR-ON	0424
ORAVA	0024,0230,0236,0513,0541		
ORBISAT	0067	ORBIT	0513
ORION	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300, 0322,0329,0352,0409,0415,0418,0447,0471,0472,0513, 0555,0557,0588,1009,1251,1368,1422,1425,1623,5423, 5437,5864,6177		
ORION (HUNGARY)	0046,0119,0230,0236,0269,0415,0441,0513,1059		
ORLINE	0513,0540		
ORMOND	0043,0097,0513		
ORSOWE	0025	OSAKA (SHORAI)	0195
OSAKI	0043,0067,0195,0513		
OSIO	0075,0513	OSUME	0540
OTAKE	0195,0300		
OTF	0046,1659		
OTHER	5013,5023,5063		
OTHER LINE	0025,0067,0236,0435		
OTTO VERSAND	0046,0047,0067,0083,0114,0125,0127,0133,0140,0162, 0162,0174,0176,0177,0178,0189,0195,0197,0209,0230, 0233,0236,0242,0296,0300,0310,0321,0326,0337,0351, 0352,0391,0409,0415,0418,0427,0434,0435,0508,0513, 0540,0555,1352,1609,1629,1632,1652,1656,1683,1684		
OVP	0236,0513		
PACIFIC	0513		
PAEL	0067,0096,1126		
PALLADIUM	0024,0069,0080,0083,0114,0148,0174,0176,0209,0227, 0295,0409,0513,0555,0588,1609,1631,1632,1636		
PALSONIK	0067,0302,0322,0329		
PANAMA	0057,0067,0236,0322,0513,0540		
PANASONIC	0260,0287,0310,0349,0402,0427,0518,1411,1609,1626, 1659,1684,1712,2027,6116		
PANAVISION	0236,0295,0322,0536,0505,1639		
PANAVOX	0067,0123,0424,0572,1121,1131,1325,1326,1446,1447,		
PANDA	0310		
PANORAMIC	0092		
PANORAMA	0067,0505,0536		
PATH MARCONI (THOMSON)	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136, 0164,0181,0229,0230,0242,0455,0549,0732,1045,1435, 1445,1478,2026		

PATH CINEMA	0025,0067,0114,0204,0230,0237,0435,1659		
PCM	0114,0236,1639	PEEKTON	6161
PEACOCK	0046,0067	PERDIO	0513
PEONY	0425,0527	PERFEKT	0513
PERSHIN	0096,0204	PHILARMONIC	0060,0067
PHILBIX (DESMET)	0025,0043,0114,0230,0236,0246,0513,1619		
PHILCO	0024,0057,0060,0102,0115,0131,0149,0227,0298,0374,0435,0513,0572,1326,1611,1636,1659		
PHILIPS	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705,5338,5402,5418,5497,5830,5834,5962,6114,6209,6210		
PHILIPS (F)(PHILIPS)	0024,0042,0046,0067,0111,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1561,1605,1607,1617,1618,1623,1629,1630,1631,1632,1633,1672,1705		
PHOENIX	0043,0046,0114,0115,0236,0238		
PHONOLA (PHILIPS)	0024,0042,0046,0067,0111,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
PIONEER	0095,0119,0162,0170,0302,0464,1508,5817,5820		
PLANTRON	0322,0513	PLATINIUM	1509
PLASMATECH	1383,1436	PLAYDOR	0322
PLAYSONIC	0024,0123,0237,0513		
POLYTRON (KATHREIN)	0513	POP	0095,0322
PORTLAND	0209,0354,0471,1638		
POWERPOINT	0513,0540		
PRANDONI	0025,0043,0077,0080,0083,0097,0115,0302,0352,0592,1126,1227		
PRECISION	0067,0329	PREMIER	0322,1116
PRIMA	0067,0322,0329,0505		
PRINCE (PRANDONI)	0025,0043,0077,0080,0083,0097,0115,0302,0352,0592,1126,1227		
PRINCESS	0329,1425	PRINSTON	0141
PROCYON (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0532,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
PROFESSOR	0046	PROFILINE	0043
PROFEX	0131,0162,0230,0298,0435,1696		
PROFILO	0025,0236,0513		
PROFITRONIC	0077,0540,1636		
PROLINE	0043,0295,0554,0375,0230,0418,1619,0170,0540,0513		
PROSONIC	0236,0415,1638,5338,5437	PROTEK	5822,5822-5867
PROTECH	0067,0097,0230,0236,0322,0336,0374,0513,1357,1631,1636,1638,1639,5338		
PROVISION	0236,0322,0354,0390,0409,0513,0540,1320		
PROTON	0547	PVISION	1489,5876
PYE (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
PYGMY	0024,1621		
QBELL	5416,5822,5822-5867,5824,5874,5963		

QMEDIA	5965,6170,6184
QUADRAL	0074
QUADRIGA	0147,0584
QUALCRAFT	0329
QUADRO	0043,0074,0552,0566,0579,1112,1410,1423,1502,1503, 1505,1506
QUASAR	0025,0077,0131,0136,0196,0237,0238,0329,1126,1383
QUEENFIDELITY (DAEWOO)	0060,0067,0209,0236,0352,0354,0361,0375,0502,0513, 0545,0554,0557,1390,1412,1449,1450,1453,1601,1644
QUELLE	0043,0046,0047,0065,0066,0067,0069,0074,0075,0077, 0083,0094,0096,0097,0102,0108,0123,0125,0136,0137, 0140,0147,0148,0149,0162,0164,0167,0174,0176,0184 0195,0196,0197,0215,0222,0230,0236,0242,0259,0282, 0287,0290,0295,0296,0298,0300,0302,0310,0312,0322, 0326,0329,0337,0339,0351,0352,0375,0390,0391,0409, 0418,0427,0431,0433,0434,0471,0513,0516,0540,0552, 0555,0558,0592,1126,1352,1629,1632,1636,1639,1649, 1650,1652,1653,1654,1656,1657,1658,1672,1674,
QUESTAR	0149,0197
R. LINE	0513,0540
RADIALVA	0236,0354,0540
RADIOLA (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705
RADIOMARELLI	0060,0024,0077,0025,0115,0230,0374,0236,1009,1639
RADIONETTE	0066,0282,1626,1654
RADIOHACK	0513,0540,0547
RADIOTONE	0107,0227,0236,0255,0322,0336,0352,0513,0536,1636, 1638
RANK / RBM	0230,0295,0435,1626,1696
RANK ARENA	0184 <b>REALISTIC</b> 0547
RECOR	0074,0176,0236,0513,0540,1637
RED STAR	0513
REDDER	0197,0233,0237
REDIFFUSION	0052,0162,5338
REDO	0354 <b>REDPOINT</b> 0549
REFLEX	0043,0097,0236,0513,0540,1636,1639,5338
RELISYS	1383
RENDER	0417,0550,1400,1412,1428,1469,1551,5415,5416,5462,5823,5825
REVOX	0176,0236,0540
REX (SELECO)	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242, 0295,0352,0390,0428,0429,0435,0440,0522,0541,1181, 1623,1642,1653
RFT (BRUNS)	0024,0077,0242,0336,0363,1623,1667
RICONH	0513,0540
RITAR	5445 <b>RITZ</b> 0230
RM 2000	0043,0097,0552,1636,1639,5338
ROADSTAR	0043,0076,0097,0141,0170,0236,0352,0528,0557,1343, 1400,1423,1435,1451,1453,1469,1525,1603,1623,1636, 1646,5451,5864
ROBERTS	0327 <b>ROBOTRON ELECTR</b> 0024,0363
ROSNER	0067 <b>RODEX</b> 0513,0540
ROWA	0067,0236,0322,0528
ROWSONIC	0067
ROYAL	0067,0236,0322,0374,0424,0543,1305,1420

<b>RUKOPIR</b>	0513,0540	<b>RUNCO</b>	1360
<b>RUEFACH (LENCO)</b>	0043,0077,0162,0236,0322,0329,0354,0391,0435,0513		
	0025,0043,0051,0055,0089,0090,0092,0094,0095,0119, 0164,0181,0229,0242,0513,1603,1626,5334,5422,6114, 6203,		
<b>SABA</b>			
<b>SAGEM</b>	0073,1552	<b>SAINEL</b>	0230
<b>SAISHO</b>	0065,0067,0083,0196,0237,0300,0322,0354,0418		
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252, 0431,0433,1626,1654,2356,4340,4341		
<b>SAITO (OCEANIC)</b>			
<b>SAIVOD</b>	0043,0236,0513,0540		
<b>SAKAI</b>	0067		
<b>SAKIO</b>	0322,0354		
	0052,0075,0080,0082,0083,0137,0147,0162,0170,0178, 0192,0236,0252,0390,0431,0433,1016,1659,1704,5958		
<b>SALORA</b>			
<b>SAMBERS</b>	0025,0077,0131,0237,0238,0329,1124,1126		
<b>SAMPO</b>	0046		
	0067,0075,0082,0170,0209,0227,0296,0312,0322,0352, 0375,0384,0422,0453,0513,0515,0528,0542,0547,0565, 1328,1356,1382,1404,1405,1644,1645,1657,1658,2066, 4267,5063,5419,5441,5444,5447,5451,5472,5498,6111		
<b>SAMSUNG</b>			
<b>SAND</b>	0170		
<b>SANDRA COLOR</b>	0025,0067		
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252, 0431,0433,1626,1654,2356,4340,4341		
<b>SANDOR (OCEANIC)</b>			
	0149,0236,0322,0415,0424,0513,0540,0541,0557,0588, 1340,1423,1469,1636,5338,5451,5437,5827,5961		
<b>SANSUI</b>			
	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314, 0363,0373,0375,1360,1423,1657,1658,1661,1668		
<b>SANWA (SANYO)</b>			
	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314, 0363,0373,0375,1360,1423,1657,1658,1661,1668		
<b>SANYO</b>			
<b>SAR</b>	0067,0083,0513		
<b>SATUM (URANYA)</b>	0025,0114,0136,0227,0236,0354,0513		
<b>SATRONIC</b>	0057	<b>SAVE</b>	0513,0540
	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300, 0322,0329,0352,0409,0415,0418,0447,0471,0472,0513, 0555,0557,0588,1009,1251,1368,1422,1425,1623		
<b>SAVILLE (ORION)</b>			
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1561,1605,1607,1617,1618,1619, 1623,1629,1630,1631,1632,1633,1672,1705		
<b>SBR (PHILIPS)</b>			
<b>SCHAUB</b>	5428		
	0043,0052,0062,0097,0147,0162,0178,0227,0236,0252, 0322,0354,0374,0384,0400,0424,0431,0433,0435,0508, 0513,0557,1393,1400,1459,1469,1475,1489,1603,1626, 1636,1638,1639,1654,5609		
<b>SCHAUB LORENZ</b>			
	0042,0043,0067,0077,0080,0097,0115,0125,0133,0141, 0153,0170,0209,0222,0230,0236,0298,0302,0329,0352, 0374,0391,0415,0434,0513,0533,0592,1269,1423,1426, 1496,1516,1533,1623,1636,1639,1648,1659,2395,4551, 5864		
<b>SCHNEIDER</b>			
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705		
<b>SCHNEIDER (F)(PHILIPS)</b>			
<b>SCHWAIGER</b>	6213		
	0025,0043,0067,0083, 0114,0136,0170,0196,0227, 0230,0236,0322,0354,0435,0513,0541,0542,1619,1636		
<b>SCOTLAND (FORMENTI)</b>			

<b>SCOTLAND (FORMENTI)</b>	1637,1639,1654		
<b>SCOTT</b>	0114,0327,0547,1317,1638,1639,6119		
<b>SEARS (SANYO)</b>	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314, 0363,0373,0375,1360,1423,1657,1658,1661,1668		
<b>SEAWAY</b>	0043		
<b>SEDIP (PATH CINEMA)</b>	0025,0067,0114,0204,0230,0237,0435,1659		
<b>SEELVER</b>	0043,0513,0540		
<b>SEG</b>	0043,0046,0057,0067,0077,0097,0123,0131,0209,0230, 0236,0252,0322,0329,0363,0435,0513,0552,0555,1227, 1423,1639,1659,5338		
<b>SEI (SINUDYNE)</b>	0024,0043,0077,0115,0127,0170,0192,0195,0196,0222, 0236,0295,0300,0352,0391,0409,0471,0528,0555,0581, 0588,1009,1422,1425,1433,1434,1565,1622,1623,1624, 1639		
<b>SEIGA (MITSUBISHI)</b>	0024,0043,0047,0065,0149,0197,0230,0353,0354,0425, 0527,0547,1379,1637,1644,1661,		
<b>SEIKO</b>	0354		
<b>SEITECH</b>	5871		
<b>SELECO</b>	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242, 0295,0352,0390,0428,0429,0435,0440,0522,0541,1181, 1623,1642,1653		
<b>SELECT</b>	0043		
<b>SEMP</b>	0337	<b>SENDAY</b>	0236
<b>SENTRA</b>	0207,1608	<b>SERINO</b>	0073
<b>SET</b>	0435,0513		
<b>SHARP</b>	0067,0149,0197,0321,1307,1421,1429,1624,1683,5432, 5455,5844,5846,6114		
<b>SHINELCO</b>	5828,5829,5841,5842,5843,5850,5851,5863,5869		
<b>SHINTOSHI</b>	0513,0540	<b>SHIVAKI</b>	0230,0513,0540
<b>SHIWAN (KAISUI)</b>	0067,0073,0236,0415,0424,1420		
<b>SHNIED</b>	0322	<b>SHORAI</b>	0195
<b>SHOV</b>	0067,0322,0415,0513		
<b>SIAREM</b>	0024,0025,0077,0115		
<b>SICANTIC (LUXOR)</b>	0052,0075,0082,0083,0123,0137,0147,0162,0170,0178, 0192,0252,0390,0431,0433,1016,1704,1713		
<b>SICE</b>	1652	<b>SIDEC</b>	0230
<b>SIEL</b>	0230		
<b>SIEMENS</b>	0039,0069,0102,0148,0184,0236,0329,0351,1609,1652,		
<b>SIERA</b>	0513,0540		
<b>SIEMSEN</b>	5481		
<b>SIESTA</b>	0336,1657		
<b>SILVA</b>	0123,0149,0298,0302,0322,0329,0513		
<b>SILVER</b>	0149,0322,0513,0540		
<b>SIMATEC (ORION)</b>	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300, 0322,0329,0352,0409,0415,0418,0447,0471,0472,0513, 0555,0557,0588,1009,1251,1368,1422,1425,1623		
<b>SIMTEL</b>	0133,0322,0424		
<b>SINGER</b>	0024,0025,0060,0067,0077,0115,0236,0415,0429,0513, 0540,1227,1311,1638		
<b>SINOTECH</b>	0322,0374,1084,1251		
<b>SINUDYNE</b>	0024,0043,0077,0115,0127,0170,0192,0195,0196,0222, 0236,0295,0300,0352,0391,0409,0471,0528,0555,0581, 0588,1009,1422,1425,1433,1434,1565,1622,1623,1624, 1639,5338,5851,5864,6177		
<b>SIREL</b>	0025		
<b>SKANTIC (LUXOR)</b>	0052,0075,0082,0083,0123,0137,0147,0162,0170,0178		

SKANTIC (LUXOR)	0192,0252,0390,0431,0433,1016,1704,1713		
SKAY	0424,0513,0540	SKY LINE	0067,0410
SKY MEDIA	5819	SLAVA	0067
SLIDING	1383,1412,1426,1453,1496,1516,1543,1549,1555,1564, 1569,2395,4551		
SMARAGD	0549		
SMR (MAXWELL)	0025,0077,0236		
SOLAVOX	0082,0162,1648,1654,1713		
SOMBER (CLARIVOX)	0024,0025,0096,0204,0237,0490,0540,1611,1659,1667,		
SONICX	0236		
SONIKO	0236,0540		
SONITRON	0024,0067,0290		
SONNECLAIR	0513,0540	SONOLOR	0162,0431
SONOKO	0123,0236,0322,0424,0505,0513,0557,1636,6211		
SONORO (AGASHI)	0236,0322,0513		
SONTEC	0125,0513,1639,1657		
SONY	0065,0140,0149,0174,0215,0339,0373,0513,0785,1084, 1352,1356,1470,1528,1656,1672,1674,3108,5414,5436, 5452,5499,6115,6117,6179		
SOUND COLOR	0043,0141,0143,0170,0236,0322,0415,0557,1415,1603, 1636,1638		
SOUND DESIGN	0547	SOUNDVISION	0077,0513
SOUNDWAVE	0074,0322,0513	SOUNDZONE	5864
SOUTHERN CROSS	1614	SOWTECH	1657
SPARKLE	0513		
SPECTRUM	0547		
SPECTRA	0236,0322,0354		
SPORT GENEXXA (FORMENTI)	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654		
SSANGYONG (SAMSUNG)	0067,0075,0082,0170,0209,0227,0296,0312,0322,0352, 0375,0384,0422,0453,0513,0515,0528,0542,0547,0565, 1328,1356,1382,1404,1405,1644,1657,1658,2066,4267		
SSS (FUNAI)	0149,0230,0322,0552,0557,1558,1663		
STAG (KAISUI)	0067,0073,0236,0415,0424,1420		
STANDARD	0046,0060,0067,0114,0513		
STAR	0236,5470,5475		
STARLINE	0236		
STARLITE	0322,1638		
STARLUX	0067,0513	START	0513
STASSFURT (BRUNS)	0024,0077,0242,0336,0363,1623,1667		
STERLING	0043,0352	STENWAY	0424
STERN (SELECO)	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242, 0295,0352,0390,0428,0429,0435,0440,0522,0541,1181, 1623,1642,1653		
STRATO	0322,0513,0540		
STRONG	1586,5467		
STT SONIG	0046	STV	0162
STVI	0067,0230	SUNIC LINE	0513
SUNKAI	0043,0073,0177,0195,0300,0447,0513,0549		
SUNNY	0415	SUNNYSKY	5453
SUNSTAR	0043,0236,0322,1354,1639		
SUNSTECH	5476,5869,6118,6119,6162	SUNWATT	0046
SUPERLA	0025,0230	SUNWOOD	0513
SUPERSONIC	0236,0322,0415,1637		

SUPERTECH	0236,0298,0415,0513,1638,1646		
SUPERTONE(PATHCINEMA)	0025,0067,0114,0204,0230,0237,0435,1659		
SUPRA	0067,0123,0322,0329,0354,0422,0547		
SUPRATECH	6167,6168,6169,6170,6173		
SUPREME	0060,0136	SWISSTEC 5819,5821	SYCLINE 0067
SYSLINE	0513,0540	SYDNEY	0067
SYTEL (DESMET)	0025,0043,0114,0230,0236,0246,0513,1619		
TADISTAR	0374		
TAISHO	0230		
TAKARA	0043	TALENT	1085
TALITA (CLARIVOX)	0024,0025,0096,0204,0237,0490,0540,1611,1659,1667,		
TAMASHI	1323		
TANDBERG	0024,0050,0092,0094,0195,0222,0246,0295,0349,0440,		
TANDY	0067,0080,0083		
TASTER	0046,0322	TASHIKO	0080
TATUNG	0375,0246,0067,0375,0176,0236,0254,0065,0513,0242 1636,		
TAUTO	0541	TCL	1523
TCM	0209		
TD DESIGN	0176		
TDA	0557	TEAM	0424
TEAC/TEAK	0043,0046,0047,0222,0391,0562,1269,1510,1607,1637 5965,6205,6206,6207		
TEC (DUAL-TEC)	0043,0047,0057,0067,0097,0123,0125,0133,0141,0153, 0158,0162,0170,0196,0209,0222,0230,0236,0298,0312, 0329,0354,0391,0409,0434,0513,0592,1400,1636,1659,		
TECCO	0067,0092		
TECHLINE	0043,0077,0097,0236,0540,0552		
TECHNEMA (FORMENTI)	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654		
TECHNICAL	0043	TECHNILAND	0302
TECHNICS	0310,0427		
TECHNISAT	0177,0236,0555,1425,1623,4127,4214,5338		
TECHNISSON	0557,1603		
TECHNOL	0067,0176,0322,0354,0513		
TECHWOOD	0043,1423		
TECNIMAGEM	0170,1452		
TECNISON	0067		
TECO (AMSTRAD)	0043,0143,0196,0222,0236,0322,0415,0513,1343,1410, 1415,1423,1425,1469,1559,1638,1639		
TECSONIC	1532		
TEDELEX	0046,0067,0230,0236,0302,0490,0528,1243,1523		
TEINEL,SA	1639,1659	TEK	1127
TEKNANT	0424,0513	TEKA	1127
TEKNIKA	1614	TEKON	0384
TELEAVIA (THOMSON)	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136, 0164,0181,0229,0230,0242,0455,0549,0732,1045,1435, 1445,1478,2026		
TELECHROM	0424,0513	TELECOR	0513,0540
TELEFUNKEN	0051,0092,0094,0095,0102,0107,0119,0141,0164,0229, 0242,0378,0513,0528,0540,0566,0579,1191,1269,1301, 1616,1650,5422,6114		
TELEFUSION	0513,0540		
TELEGAZI	0162,0391,0513,0540		
TELEKTRON	0077	TELEMASTER	0513

TELEMEISTER	0540	TELEPOINT	0236
TELESONIC	0513,1338	TELERENT	0176
TELESTAR	0074,0236,0302,0322,0336,0536,5864		
	1400,1426,1475,1496,1548,2395,4551,5422,5482,5489,		
TELESYSTEM	5838,5873		
TELETECH	0043,0057,0097,0236,0540		
TELETON	0067,0083,0108,0149,0153,0158		
TELEVIEW	0513,0540	TELEWIRE	5485
TELRA	0513	TELEXA	0077
TEMPEST	0067,0513,0540		
TENNESSEE	0236,0540	TEMCO (SHORAI)	0195
	0043,0046,0060,0066,0067,0077,0097,0114,0195,0209,		
	0230,0236,0238,0282,0302,0352,0354,0415,0513,0540		
TENSAI	1632,1636,1639,1659		
TESLA	0024,0046,0230,0236,0237,0352,0415,0528,5338		
TESLA SLOW (TESLA)	0024,0046,0230,0236,0237,0352,0415,0528		
TETTRAN	0114,0230		
TEVION	0043,0209,0286,0513,0557,4603,5481,5851		
TEXET	0067	TFT	1493
THES	1526,1600,5433,5434,5437,5476,5564,5826,5847,5873,6158,6162		
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,		
	0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,		
THOMSON	1445,1478,2026,5836,5837		
THOMSON 2100	5023	THOMSON 3004	5013
	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,		
THORN	0513,1616,1663,1700		
TIME	1400,1489,1537	TLOGIC	5872
TMK	0196,0547		
TOBISHI	0067,0195,0322,0384		
TOBO	0322	TOKO (KATHREIN)	0513
TOKAI	0043,0236,0322,0435,0540		
TOKIWA (TOKAI)	0043,0236,0322,0435,0540		
TOKYO	0384,0424,1608		
TOMASHI (KAISUI)	0067,0073,0236,0415,0424,1420		
TOMITA	0067	TOPSHOW	0322
TOP VISION	0230,0238,0435,0513		
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,		
	0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,		
TORRE (THOMSON)	1445,1478,2026		
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523,0557		
TOSHIBA	1423,1608,1678,1681,1694,5422,5448,5558,6112,6121		
TOWADA	0077,0230		
	0043,0097,0170,0513,0588,1383,1425,1434,1437,1452,		
TRANS CONT.	1453,1564,1569		
TRANSONIC	0322,0513,0528,0536,1607		
	0149,0230,0424,1343,1525,1549,5825,5883,5884,5885,		
TREVI	5886,5887,5888,5958,5965,6159,6203		
TRIAD	0237,0513,0540	TRIDENT 0067	TRILUX 0521
TRISTAR	0046,0374		
TRIUMPH	0196,0513,0540		
TSOSHI (KAISUI)	0067,0073,0236,0415,0424,1420 TSVISION 5831,5887		
TTR	1455,		
TVSTAR	1696	TVD	0043
	0077,0083,0108,0114,0133,0153,0176,0238,0513,0540,		
UHER	1126,		



ULTRAVISION	0237,0290		
	0050,0077,0354,0067,0513,0236,0409,0125,0115,0189,		
ULTRAVOX	0024,1639		
UNDERWOOD	1391		
UNIC RADIO	0025,0067,0123,0435,1657,1659		
UNIMOR	0236,0336,0153,1657	UNITECH	5864
	0043,0141,0145,0541,0557,1400,1423,1603,1657,5415,		
UNITED	5422,5433,5437,5454,5476,5849,5850,5864,6120		
UNITRON	0595		
	0043,0046,0047,0065,0066,0067,0069,0074,0075,0077,		
	0083,0094,0096,0097,0102,0108,0123,0125,0136,0137,		
	0140,0147,0148,0149,0162,0164,0167,0174,0176,0184,		
	0195,0196,0197,0215,0222,0230,0236,0242,0259,0282,		
	0287,0290,0295,0296,0298,0300,0302,0310,0312,0322,		
	0326,0329,0337,0339,0351,0352,0375,0390,0391,0409,		
	0418,0427,0431,0433,0434,0471,0513,0516,0540,0552,		
	0555,0558,0592,1126,1352,1629,1632,1636,1639,1649,		
UNIVERSUM (QUELLE)	1650,1652,1653,1654,1656,1657,1658,1672,1674,1676		
UNIVOX	0024,0162,0237,0540,1659		
UNK	0025,0043,0230,0236,0375,0557,1636		
URANIA (SAMBERS)	0025,0077,0131,0237,0238,0329,1124,1126		
URANYA	0025,0114,0136,0227,0236,0354,0513		
UTAX	0067		
VANGUARD	0083,0123		
VENTANA	0043		
VDTECH	6161		
	0042,0043,0057,0083,0097,0230,0236,0298,0513,0552,		
VESTEL	1423,1631,1636,1639,5338,6114		
VEXA	0067,0424,0513		
VICEROY	0067,0322,0329,1082		
VIDEOLOGIC	0067,0322	VIDECON	0046
VIDEOMAC	0067,0322	VIDEON	0236
VIDEOSAT	0057,0125	VIDEOSYSTEM	0540,1636
	0043,0060,0067,0097,0119,0178,0290,0302,0374,0391,		
VIDEOTON	0435,0441,0540,1423,1659		
VIDESON	0230	VIDITAL	0322
VIDIKRON	0077,0114,1661		
VISIOLA (PATH CINEMA)	0025,0067,0114,0204,0230,0237,0435,1659		
VISION 2000	0236,0322,0540,1636		
VISION MAGIC	1412	VISIONREX	0025
VISIOSAT	1599	VISTAR	0203,0431
	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,		
VISTA (THORN)	0513,1616,1663,1700		
VORTEC	0145,0513,0540		
VOXSON	0024,0080,0136,0322,5609,5850		
VSM	0181	WAGNER	1654
WALKIE	0153,0295	WALKVISION	0043
	0043,0060,0067,0097,0119,0178,0290,0302,0374,0391,		
WALTHAM (VIDEOTON)	0435,0441,0540,1423,1659		
	0043,0046,0080,0097,0105,0114,0115,0196,0209,0236,		
WATSON	0322,0513,0536,0552,1636,1639,		
WATT RADIO	0067,0077,0115,0060,0227,0238,0298,0513,1657		
WEBER	0047,0125,0322		
WEGA VISION	0024,0149		
	0043,0057,0097,0141,0236,0302,0322,0374,0528,0540,		
WEGAVOX	0555,0592		

WELLFUND	0424		
WELLINGTON	0043	WELLTECH	0557
WELTBlich	0114,0236,0513,0540,1638,1639,1646		
WESTON	0424,0435,0540		
WESTWOOD	0043,0170,0540,1338		
WHARFEDALE	0170,0540,1338		
	0067,0077,0083,0108,0114,0115,0131,0136,0153,0227,0230,0236,0295,0322,0374,0424,0435,0513,0541,1636,1639,1658,1659		
WHITE WESTHINGHOUSE			
WILSON	0043		
WINDSOR	0043,0097,0513		
	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,0513,1616,1663,1700		
WINDSTAR (THORN)			
WINDY SAM	0540	WINNER	1346,
WINSTON	0043,0424,0513		
WINTERNITZ	0097,0354,0497		
WORLD TECH	0513		
WORLDVIEW	0046,0415,1636		
WOV	1450	WREMEN	0238
XCELLENT	0513,1338,1638		
XENA	0204	XONYCS	0236
XRIPTON	0074,0236,0540,1638		
YAMISHI	0424,0540	YOCAN	0540
	0067,0092,0125,0207,0230,0236,0290,0322,0354,0329,0435,0516,0540,1696		
YOKO			
YOSHITA	0513,	YOTAKA	0513
YUMATU	0074,0322,0374,0415		
ZANELA	0321,	ZAMPA	0052
	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653		
ZANUSSI (SELECO)			
ZAPP	5338,5414,5418,5422		
ZEM	5338,5418,5422	ZEPHIR	5464,5825
	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653		
ZOPPAS (SELECO)			



