



nedis

TVWM5550BK INSTALLATION MANUAL



A (x1)	B (x1)	C (x1)	D (x2)
E (x1)	F (x1)	G (x1)	H (x2)
M5x14 (x4) M-A	M6x14 (x4) M-B	M8x20 (x4) M-C	M6x30 (x4) M-D
M8x30 (x4) M-E	(x4) M-F	(x8) M-G	(x4) M-H
W-A(x5)	W-B(x5)	W-C(x4)	

